


J

Ersatzteile - Spare parts - Pièces de rechange - Reserveonderdelen - Parti di ricambio - Reservedele - Reservdelar
рзапчыны - Запасныя часты - 备件





①	Steuerung	Control unit	
	1010/4 BWE		JP47285
	1010/4, 1015/4		JP47286
	1025/4, 1025/2		JP45786
	1035/2		JP45787
②	DN 150 / DN 100	DN150 / DN 100	JP48871
③	Klemmflansch	Clamping flange	JP43713
④	Wartungsdeckel	Service lid	JP42798
⑤	Überschiebmuffe	Collar	JP47287
⑥	Behälter	Tank	JP44861
⑦	Steuerungsplatine	Control board	JP47304
⑧	Niveauerfassung	Level control	
	4 m Leitung	4 m cable	JP43712
	15 m Leitung	15 m cable	JP48227
⑨	Pumpenlüftung	Pump ventilation	JP43710
⑩	Auftriebssicherung	Anti floating	JP43709
⑪	Pumpe	Pump	
	1010/4 BWE, 4 m		JP46754
	1010/4 BWE, 15 m		JP48684
	1010/4		JP45778
	1015/4		JP45779
	1025/4		JP45780
	1025/2		JP48826
	1035/2		JP48827
⑫	Elast. Verbindung	Elastic connector	JP43705
⑬	Gehäuse Klappe	Housing valve	JP46813
⑭	Flansch	Flange	JP43706
⑮	Doppelklappe	Duplex flap	JP46812
⑯	Basisplatte	Base plate	JP43714
⑰	Dichtband	Sealing tape	JP47966



① Leitung	Cable	
10/4, 15/4, 25/4		JP43717
1010/4-BWE, 4-m		JP43721
1010/4-BWE, 15-m		JP48685
② Stator	Ordnung	Stator
JP48682	10/4	
JP48681	10/4	
JP48680	10/4	
JP48686	10/4	
③ Rotorwellen	Rotor shaft	
JP48791	10/4	
JP48801	10/4	
JP48806	10/4	
④ Immoeller fixat	Immoeller fixat	
JP48802	10/4, 15/4, 25/4	
⑤ Bearing set	Bearing set	
JP48774	10/4	
⑥ Lagersatz	Lagersatz	
JP43720	10/4	
⑦ Dichtungs	Dichtungs	
JP48807	10/4	
⑧ Dichtung	Dichtung	
⑨ Gehäuse	Gehäuse	
JP48790	10/4	
JP48793	10/4	
JP48794	15/4	
JP48795	25/4	
⑩ Schrauben	Screws	
JP48683	10/4	
JP48684	15/4	
JP48685	25/4	

