



# J

Ersatzteile - Spare parts - Pièces de rechange - Reserveonderdelen - Parti di ricambio - Reservedele - Reservdelar  
Запасные части - 备件






①	n on o n	
	B	JP47285
		JP47286
	? ? ? ?	JP45786
	?	JP45787
②		JP48871
③	c	JP43713
④	n d c v c d	JP42798
⑤	c o	JP47287
⑥	B	JP44861
⑦	n on o	JP47304
⑧	v n L v con o	
	L n c	JP43712
	L n c	JP48227
⑨	n M n n ion	JP43710
⑩	A c n An o n	JP43709
⑪		
	B	JP46754
	B	JP48684
		JP45778
		JP45779
	?	JP45780
	? ?	JP48826
	?	JP48827
⑫	n c conn c o	JP43705
⑬	o n v	JP46813
⑭	c	JP43706
⑮	o	JP46812
⑯	B B	JP43714
⑰	c d n	JP47966



① Leitung	Cable	
25/4	JP43717	10/4, 15/4
VI, 4 m	JP43721	1010/4 BA
VI, 15 m	JP43695	1010/4 BA
Motorhäuse	Stator + Housing	② Stator + C
10/4, 15/4	JP43700	10/4, 15/4
BWE: I	JP43722	1010/4 BA
Welle	Rotor shaft	③ Rotorw
10/4, 15/4	JP43791	10/4, 15/4
BWE: I	JP43801	1010/4 BA
Dichtung	Motor seals	④ Motora
	JP43806	
Befestigung	Impeller fixation	⑤ Laufrad
15/4, 25/4	JP43802	10/4
Lagersatz	Bearing set	JP43726
Lagerschild	Bearing housing	JP43720
Dichtungssatz	Seal set	JP43807
Laufrad	Impeller	



UC 25/2 - 35/2

①	L n	ab	JP43717
②			
